

# SOFTWARE DEVELOPMENT KIT

### LandMark™ 01/10/20/21/22/30/40/50 (IMU/VG/AHRS)




IMU Data in Full Mode at 1kHz Data Rate



AHRS Selectable 100-200 Hz Data Rate



Software Development Kit



GUI Attitude Indicator Display

#### **Included in SDK**

- ✓ SKD User Manual
- ✓ RS485 to USB Converter
- ✓ Cable to Converter Board
- ✓ Cable to IMU
- ✓ SDK Software
- RS485/RS422 to USB Interface
- Programming & Self Test Switch

Export Classification: Commerce ECCN7A994 (NRL)



Inertial Unit to CPU Interface Module

The LandMark<sup>™</sup> Software Development Kit (SDK) is an optional product to assist first time users of the LandMark<sup>™</sup> in order to facilitate a rapid setup, test and use of the unit.

#### **Features**

- Begin outputting data in minutes using the LandMark™ turnkey SDK
- USB Power direct from PC or LandMark™ remote power supply
- All cabling, Interface connectors & software included and ready for use
- Easy integration of direct inertial RS485/RS422 to PC's USB interface
- Includes PC display software
- Data record capability
- User defined bandwidth and filter settings
- Selectable Data output rate on inertial
  unit

#### Overviev

The LandMark<sup>TM</sup> SDK includes all cabling required to interface directly from the MEMS RS485 interface to a PC's USB interface. The converter cable includes battery powered power supply (there is also wiring on the cable to enable the user to supply their own +3.0V to +4.2V power) and a self-test switch. The battery power supply uses three 1.5 Volt AA batteries (included with shipment) and supplies user battery power on the IMU for about 19 hours typical.

#### **PC Display Software**

Enables users to display each channel of rate, acceleration and temperature as well as to monitor Self-Test parameters. The software also enables the user to record data sets of their choosing via .CSV format for export in Excel or other user database. Additional features allow user selectable setting of the bandwidth filter and output data rate.

#### Support

Please contact your local Gladiator Technologies Representative for in-country service and support.

Additional software updates and documentation can be found on our website under the product page.

## Gladiator Technologies Division LKD Aerospace, Inc

8020 Bracken Place SE Snoqualmie, WA 98065 USA Tel: 425.396.0829 Fax: 425.396.1129 Email: sales@gladiatortechnologies.com Web: www.gladiatortechnologies.com




# SOFTWARE DEVELOPMENT KIT

#### LandMark™ IMU

### 

IMU Data in Full Mode at 1kHz Data Rate

#### **LandMark™ AHRS**




AHRS Data in Full Mode at 200Hz Data Rate




Gladiator IMU Display 1.2.70.6 Copyright (C...

Mode Load Units View Com Port Baud Rate

a Rate Select IMU Mode at 200 Hz Data Rate



Data Rate Select Data Rate Select









Gladiator AHRS Display 3.2.70.7 Copyright (C) 2007-2014 Gladiator Technologi.

Gladiator AHRS Display 3.2.70.9 Copyright.

0.06351 deg

-0.23798 deg

0.55508 deg

0.05500 m/s

Mode Load Units View Com Port Baud Rate

Set Spec Mode 200Hz

Set Spec Mode 100Hz

Set Full Mode 200Hz

Set Full Mode 100Hz

Clear

Units of Measure Select Data Recording

Gladiator Technologies Division LKD Aerospace, Inc

8020 Bracken Place SE Snoqualmie, WA 98065 USA

Tel: 425.396.0829 Fax: 425.396.1129 Email: sales@gladiatortechnologies.com Web: www.gladiatortechnologies.com

